



SCW-S Series (Super Clear Water) Ultra-pure Water Reverse Osmosis Membrane has a high desalination rate, high anti-pollution and high removal rate of boron, silicon, germanium and other element so that to avoid effluent water quality of EDI system being affected by the influent water quality. The chemical cleaning cycle of the membrane is long, but its quality of effluent water is stable, which is especially suitable for the desalination module before the EDI system of the ultra-pure water in the microelectronics industry.



Product Models

	Product Models	Ft² (m²)	GPD (m³/d)	%					
	SCW-S 01	85 (7.9)	2700 (10.2)	99.7%					
	SCW-S 02	90 (8.4)	2850 (10.8)	99.7%					
	SCW-S 10	375 (34.8)	11800 (44.7)	99.7%					
	SCW-S 20	400 (37.2)	12500 (47.3)	99.7%					
Notes: The average desalination rate is tested after 24 hours operation. Flow fluctuation range of single membrane could be ±25%.									

Average Flow Rate

Pressure Drop of

Anti-expansion Device

Average Rejection Rate

Max Operating

Test Condition: 2000ppm NaCl solution, 225 psi operating pressure, 25°C temperature, pH=7, 15% recovery rate.

Max Operating

Parameters of Membrane Operating and Cleaning

Typical Operating

Effective Area


Product Models

	Pressure	Pressure	Single Membrane		remperature
SCW-S Series	600psi	225psi	<12psi	15%	50°C
Max Cleaning Temperature	PH Range of Continuous Working	PH Range of Cleaning	Allowable Max Contents of Residual Chlorine		Inlet Water
50°C	4.0-11.0	0 2.0-11.5 500ppm-h		n-h	NTU <1 SDI < 5



Anti-expansion Device

Membrane Schematics



С

2.4

(6.1)

Diameter Inch(cm) Specifications Joint

Package Weight

(kg)

3

Recovery Rate



(101.6)

Male Joint

Specifications and Parameters

			20,000							
4040	Male Joint	40.00 (101.6)	0.75 (1.9)	3.9 (9.9)	4					
8040	Flat Joint	40.00 (101.6)	1.125 (2.85)	7.9 (20.1)	16					
Special Notes:										

В

0.75

(1.9)

Storage Conditions

2540

Before the first use, all membrane elements must be stored under the original packaging conditions.

Α

40.00

 The membrane is best placed in the original packaging and opened before the using of water treatment system. The transport temperature below 0°C may cause irreversible membrane damage, and the transport temperature above 30°C

may cause membrane degradation and deterioration of the protection solution.

- Store in a cool, dry condition and the place where is not directly exposed to sunlight or artificial lighting. Storage temperature stays at 0°C to 30°C, and the longest storage time is 6 months.
- General Information
- Once wetted, the membrane element must always be wet. The limited warranty we promised will expire due to the fact that the user does not strictly follow the operational restrictions and



• If the system is in a shut down state for a long time, the membrane element is advised to be placed in the protective solution to

guidelines set forth in this Code.

O-ring

Figure 1


top of the foam

cover.

Assembly of membrane elements and components

Top

- prevent the growth of microorganisms. • It is the user's responsibility if use an incompatible chemical and lubricant, and cause undue influence on the original.
- The maximum allowable pressure drop of single pressure vessel is 60 psi (4.1bar). At no time can the backpressure be produced on the side of producing water to avoid the occurrence of harmful problems.
- INSTALLATION METHOD OF MEMBRANES



Component Part Names Required Quantities Seal Ring of Concentrated Water One Piece for Every Membrane

Four Pieces for Every Membranes Open-type Product Water Adapter One Piece for Every Pressure Vessel One Piece for Every Pressure Vessel Close-type Product Water Adapter Numbers of Membrane Elements- Numbers of Pressure Vessels Product Water Connecting Pipe

the O-rings. Put the assembled adapter in a clean place before inserting the water pipe (Figure 1).

Figure 2


Concentrated Water

Direction

Figure 4

Figure 5

3. Attach O-rings to the membrane elements. Lubricate with glycerin during installation and carefully install to prevent scratches on



INSTALLATION METHOD OF MEMBRANES

Figure 3

Explanation: the packing bag is made of a material that has a very high oxygen isolation effect, which can extend the storage time of the

storage solution. If the packing bag is cut only from one end, it can be stored for use when the membrane needs to be stored and transported.

1111111



1. Install the concentrated water seal 2. Install the membrane connectors and use lubrication when necessary. Concentrated

Water Seal

Inlet Water

Direction

Concentrated Water Seal

c. Open the inlet of the RO pressure vessel.

water seal (Figure 4).

3. Membrane Element Filling

with water and glycerin. About 10 ml of glycerol is required for each pressure vessel. If the viscosity of glycerol is high, it can be diluted with water to ensure adequate wetting. Use a mop

a. This work is best done by two people.

Note: the seal ring must not be installed on the

b. As shown in the figure, confirm the position

and direction of the V-type concentrated

concentrated water side of each membrane.

d. Lubricate the inside of the RO pressure vessel

- or similar tool to lubricate the entire pressure vessel (Figure 5).
- e. After lubricating the seal ring of concentrated water and inner wall of the pressure vessel with glycerin, install the membrane approximately 2/3
- from the inlet of the pressure vessel (Figure 6). Carefully and smoothly install the membrane, especially the first membrane. Figure 6 f. Install the concentrated water seal as the first membrane. Use a membrane adapter to connect two membranes (Figure 7).
- Partially load membrane elements at the fixed place and push the two pressure vessels safely and forcefully to keep them in a straight line and avoid damages to the membrane adapter or the concentrated water seal. g. Repeat the above steps to load the membrane element into the pressure vessel one by one. When the last membrane

element is installed, load the product water adapter provided by the pressure vessel manufacturer and push it into the

position to ensure that the first loaded membrane has been connected tightly.

